

MetPrep Preparation Procedure – No 202



Lead – Lead Sulphate Battery Section

	Surface	Abrasive	Pressure		Speed – Dir	Time
			Psi	N		
			Primary Grinding Stage	Paper		

	Surface	Abrasive	Pressure		Speed – Dir	Time
			Psi	N		
Additional Grinding Stages	Planocloth H	15 µm (OB) PCD Diamond	5	25	250 – Comp	5 mins
			5	25		
	Planocloth	6 µm (OB) PCD Diamond	5	25	250 – Comp	4 mins
	Planocloth	0.3 µm Alumina	3	15	100 – Comp	4 mins
	Chrysalis	0.06 µm Silco	3	15	100 – Contra	10 mins